

HELP US SERVE YOU BETTER BY FILLING OUT THIS QUESTIONNAIRE:

1. Your caller will be used for:

- Sport Hunting
- Predator Control
- Photography
- Bird Watching
- Research
- Other \_\_\_\_\_

2. Primary wildlife to be called: (check one)

- Predators
- Crows
- Game Animals
- Other \_\_\_\_\_
- Birds

3. How many times do you anticipate using your caller per year?

- 0-5
- 6-10
- 11-25
- 26-50
- 51+

4. How many callers have you owned prior to purchasing this unit? \_\_\_\_\_

## CALLING ACCESSORIES

Johnny Stewart offers numerous wildlife calling products and accessories, including cassettes and mouth calls.

## INSTRUCTIONAL TAPES & VIDEOS

Learn from the experts the most effective way to call wild animals and birds. Johnny Stewart produces audio cassettes and video instruction tapes on the secrets of calling ducks, predators, bucks and turkeys.



Gerald Stewart

### IMPORTANT NOTICES & RETURN POLICY

If you experience difficulty or should servicing be necessary, please call:

H.S. Industries, Inc.  
Johnny Stewart Wildlife Calls

**1-319-395-0321**

If your unit has been damaged in transit, file a claim with the carrier and report the damage to us immediately.

Please fill out and return the warranty card that is provided.



*is a subsidiary of*  
Hunter's Specialties, Inc.  
6000 Huntington Ct. NE  
Cedar Rapids, IA 52402  
[www.hunterspec.com](http://www.hunterspec.com)



## PREYMASTER DIGITAL CALLER OPERATING INSTRUCTIONS



### PREYMASTER DIGITAL CALLER

Your new PreyMaster Digital Caller is backed by 40 years of experience. The PreyMaster will create incredible fun and success for your enjoyment of the outdoors. Whether used for hunting, photography or observation of wildlife, the PreyMaster will create opportunities for you to experience nature up close in a dynamic way.

## POWER SOURCE

The PreyMaster is powered by four AA batteries. Maximum performance is provided by alkaline batteries. The PreyMaster will automatically shut down if unit remains inactive for a period of five minutes. This acts to conserve battery power.

## CALLING OPERATIONS

To begin calling place the AA batteries in the PreyMaster unit. Ensure that the batteries are installed correctly. Improper battery installation will prevent the unit from operating. Locate speaker in your selected location. Note that you can use the 10 feet of speaker cord for short-range locations, or add the 50-foot extension for longer ranges. Insert speaker cord jack into the receptacle on top of the PreyMaster unit. Select sound card containing the sounds you desire, and insert into PreyMaster. Push on sound card until you feel the snap as the sound card engages the internal receptacle. Turn unit on by pressing the on/off button. Note that the unit will not turn on if a sound card is not installed. Red LED light will illuminate when unit is turned on. Begin calling by pressing the button located next to the desired sound. Increase volume by pushing the volume up button. Decrease volume by pushing the volume down button. There are eight levels of volume. Volume automatically resets to level four each time unit is turned off/on. When finished with the PreyMaster, press on/off button to turn off unit, and remove sound card.

If you desire two sounds to play simultaneously, push one sound selection first, and then push the second selection. Both sounds will now play at the same time. You can cycle the sounds by continuing to push the sound buttons, and the sounds associated with the last two buttons pushed will play.

Storage of PreyMaster with sound card in place allows small drain on batteries that over a long period of time will reduce battery life. Insert soft plug into chip insertion slot to keep out dirt and debris.

## BELT LOOP

The belt loop on the back of the PreyMaster is removable. To remove, pull backside of locking tab toward you while pulling down on the tab. To re-install, align side rails on belt tab with slots and push upward until lock tab engages.

## STORAGE

For proper storage ensure that the caller is turned off and the sound chip removed. Storing the PreyMaster with a sound chip inserted allows slow drain on the batteries and will shorten battery life over a long period of time. If you intend to store your PreyMaster for an extended period, the AA batteries should be removed from the unit.

## MAINTENANCE

With proper care your PreyMaster requires little or no maintenance. Always use the soft plug to cover the sound card insertion slot when not in use. Contact cleaner can be used to clean the contact pins on the sound cards if they become dirty with usage. Sound cards should be stored in the protective pouches provided.

Look for these other fine products from



612-LR Deluxe Professional Caller w/ Long Range Speaker



PPC-1 Power Pro Convert-A-Caller



An Extensive Sound Library that includes CDs & audio cassettes



Cut along dotted line for WARRANTY/REGISTRATION CARD. Please fill out card completely and return to: Johnny Stewart Wildlife Calls, 6000 Huntington Ct. NE, Cedar Rapids, IA 52402

### WARRANTY REGISTRATION CARD

NOTICE: This card must be filled out and mailed within 2 weeks of the date of purchase.

(Please Print Plainly)

Name of Unit Purchased \_\_\_\_\_  
Date of Purchase \_\_\_\_\_  
Serial Number \_\_\_\_\_  
Unit Was Purchased From \_\_\_\_\_  
City \_\_\_\_\_ State \_\_\_\_\_  
Name \_\_\_\_\_  
Address \_\_\_\_\_  
City \_\_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_\_

### PREYMASTER WARRANTY

Your Johnny Stewart PreyMaster Digital Caller is a quality product, fully warranted against defects in materials or workmanship for a period of one year from the date of purchase. Faulty parts covered under this warranty will be replaced free of charge. If it becomes necessary to return your unit for repair, all shipments must be insured and prepaid to and from the factory. This warranty is void if the warranty card has not been returned to us at the time of purchase.

This warranty shall not apply if the unit has not been operated in accordance with the instruction or the machine has been altered, repaired, mistreated in any way that we believe has caused the failure or destruction of the unit. This warranty is in lieu of all other expressed or implied except for any special written agreement entered into with Johnny Stewart.